




How to setup IRQ and I/O address



PC MIDI Card Interrupt selection



PC MIDI Card I/O address selection



Daughterboard volume selection jumpers P9 & P10

LOUD:



MEDIUM:



QUIET:







AUX header pinout

Left channel
Ground
Ground
Right channel




Be **VERY** careful and correctly align your MIDI Daughterboard to the header on the PC MIDI card, failure to do so can cause irreversible damage to your equipment!

PC MIDI MPU Card IHMQ14 DB9 breakout cable schematic



PC MIDI MPU Card IHMQ14 MIDI-OUT jack schematic



PC MIDI MPU IH9MQ14
Full documentation & software
download: <http://bit.ly/1Qk2D69>



Visit **SERDASHOP** for all your DreamBlaster / audio needs!
www.serdashop.com